

Purito Modulus Furniture

Purito Modulus can be used as a freestanding unit with flush doors, available in various configurations, including drawer, door, and storage options



Features

Locks

Units can be supplied with budget locks on request

Lipping

Blue, Grey and Woodgrain

Handles

Aluminium or blue powder coated



CS Medical's Purito furniture is designed and manufactured from a unique Sealwise board.

This closed-celled UPVC/PVC sandwiched board with antibacterial Biomaster technology built-in guarantees long-lasting barrier protection against bacteria growth. While similar in weight and density to MDF, it offers 2.5x better screw retention and being 100% waterproof offers zero swelling. Purito is highly durable, easy to clean, chemically resistant, anti-static and Formaldehyde free. These features make Purito furniture the ideal unit to replace Chipboard based furniture in hospital environments.

We offer a wide range of storage solutions to suit HTM 63 and HTM 71 requirements in both Purito Modulus and Staticus ranges. Options include general storage for utility rooms, mobile cupboards, bedside lockers and wardrobes. The units are white, and we can offer bespoke printed facias on request. Both our ranges are available with two handle colours, three contrasting lipping colours.

PURITO MODULUS

Specification

- Available as modular freestanding furniture.
- Doors: Flush mounted, 16mm flush Biomaster Antibacterial coextruded U-PVC/PVC board.
- Door Edge Treatment: PVC lipped
- Access: Doors with adjustable hinges recessed flush with face of unit. Also available with drawers.
- Carcase: 16mm flush Biomaster Antibacterial, coextruded U-PVC/PVC sandwich board with seamless formed corners. Precise height managed from adjustable legs when used in fixed position or mounted on castors for mobile units.
- Carcase Edge Treatment: PVC lipped.
- Lock: Budget lock with suited keys available.
- Colour Options: White with blue, grey and woodgrain lipping.
- Handles: Aluminium C handle available in Aluminium of Blue powder-coated finish.
- Accessories: Available with Storage trays and shelves.

