

## Purito Staticus Furniture

**Purito Staticus** is a built-in unit with surface mounted doors, available in various configurations, including drawer, door, and storage options.



### Features

#### Locks

Units can be supplied with budget locks on request

#### Lipping

Blue, Grey and Woodgrain

#### Handles

Aluminium or blue powder coated



CS Medical's Purito furniture is designed and manufactured from a unique Sealwise board.

This closed-celled UPVC/PVC sandwiched board with antibacterial Biomaster technology built-in guarantees long-lasting barrier protection against bacteria growth. While similar in weight and density to MDF, it offers 2.5x better screw retention and being 100% waterproof offers zero swelling. Purito is highly durable, easy to clean, chemically resistant, anti-static and Formaldehyde free. These features make Purito furniture the ideal unit to replace Chipboard based furniture in hospital environments.

We offer a wide range of storage solutions to suit HTM 63 and HTM 71 and modular requirements in both Purito Modulus and Staticus ranges. Options include general storage for utility rooms, mobile cupboards, bedside lockers and wardrobes. The units are white, and we can offer bespoke printed facias on request. Both our ranges are available with two handle colours, three contrasting lipping colours.

### Specification

- Available as Built-in furniture.
- Doors: Surface mounted, 16mm Biomaster Antibacterial coextruded U-PVC/PVC board.
- Door Edge Treatment: PVC lipped.
- Access: Doors with adjustable hinges. Also available with drawers.
- Carcase: 16mm Biomaster Antibacterial, coextruded U-PVC/PVC board, screwed construction, with solid back. Precise height managed from adjustable legs.
- Carcase Edge Treatment: PVC lipped.
- Lock: Budget lock with suited keys available.
- Colour Options: White with blue, grey and woodgrain lipping.
- Handles: Aluminium C handle available in Aluminium or Blue powder-coated finish.
- Accessories: Available with Storage trays and shelves.

